



## CHAIR WITH RIBBED BACK

# WOODSTOCK 014

Woodstock 014 is a stylish chair with horizontal and slightly curved ribs in the back. All for increased comfort and accessibility. The chair is available in both oak and birch. It comes with removable upholstery in the seat to facilitate washing.

Woodstock är ritad av Ruud Ekstrand.



## ADDED VALUE

- Stackable
- Linkable
- Rubber fabric as standard
- Removable upholstery (seat)
- Any color
- Tested for public use and meets the requirements for durability & safety, set forth in the following standard, EN 16139

## ACCESSORIES

- Frame in birch or oak
- Frame in any color
- Rubber fabric/hospital fabric
- Sliding wheels
- Coupling fittings
- Fixed back upholstery

## REUSE

- Solid wood
- Removable upholstery (seat)

## DIMENSIONS

Height	81 cm
Width	42 cm
Depth	54 cm
Seat height	46 cm
Seat depth	40 cm




Any color available as an option on this product.

## CERTIFICATIONS



## VIEWS



NC Nordic Care AB

Box 30 573 35 Tranås Sweden

+46(0)140-38 40 60, info@ncnordiccare.se

ncnordiccare.se



## FABRIC

- Removable and washable fabrics are washed according to washing instructions. These are sewn with a shrink seam, wash before use for optimal fit.
- Vacuuming with a soft nozzle is often sufficient for cleaning.
- Stains should always be removed as quickly as possible. In most cases, wiping with a damp cloth is sufficient, for more difficult stains, a pH-neutral detergent or a foam detergent for professional use can be used.
- Always use white cloths and avoid wetting a woolen fabric to a greater extent, as this risks remaining stains.
- If necessary, a foam detergent can also be used for a more thorough cleaning if this is allowed in the fabric's specification.

## WOOD

Wood is a living material whose grain from the very beginning has a natural variation in pattern, color tone and luster. The wood is affected by, among other things, the season, heat and humidity. That wood is a living material means:

- Screws need to be re-tightened regularly, at least once a year.
- Solid table tops can naturally warp by up to 0.5%.
- Light from the sun and lighting can cause permanent color and light differences in the surface, so allow the entire wooden surface to be exposed to the same amount of light.

Out of concern for the environment, we paint a large part of our range with water-based surface treatments. This means:

- Spills of coffee and other liquids need to be wiped up immediately.
- For cleaning, hand washing detergent or pH-neutral detergents and lukewarm water are recommended. Wipe off with clean water and wipe dry. Do not use cleaning agents that are alkaline, aggressive, contain abrasives or solvents.
- For disinfection, non-alcohol-based agents are recommended, e.g. Virkon or DAX Alco Free. Alcohol-based agents must not be used.