



FOOTSTOOL

FREJA 246

Freja footstool is adjustable in two positions and a beautiful complement to the Freja armchair 236, and the frame is also made of solid birch. The footstool is upholstered with a removable cover so it can be easily kept hygienic. Rubber fabric is available as an option. It is available clear lacquered or stained in black or white as standard or in any color for an extra charge.

Möbelfamiljen är tillverkad i FSC®-Mix och är märkt med Möbelfakta. Freja är ritad av NC Design Studio.

DIMENSIONS

Height	40 cm
Width	52 cm
Depth	38 cm

CERTIFICATIONS



VIEWS



ADDED VALUE

- Adjustable in two positions
- Removable upholstery
- Any color
- Tested for public use and meets the requirements for durability & safety, set forth in the following standard, EN 16139

ACCESSORIES

- Frame in birch or oak
- Wooden base in any color
- Rubber fabric/hospital fabric

REUSE

- Solid wood
- Removable upholstery

NC Nordic Care AB

Box 30 573 35 Tranås Sweden
 +46(0)140-38 40 60, info@ncnordiccare.se
 ncnordiccare.se



FABRIC

- Removable and washable fabrics are washed according to washing instructions. These are sewn with a shrink seam, wash before use for optimal fit.
- Vacuuming with a soft nozzle is often sufficient for cleaning.
- Stains should always be removed as quickly as possible. In most cases, wiping with a damp cloth is sufficient, for more difficult stains, a pH-neutral detergent or a foam detergent for professional use can be used.
- Always use white cloths and avoid wetting a woolen fabric to a greater extent, as this risks remaining stains.
- If necessary, a foam detergent can also be used for a more thorough cleaning if this is allowed in the fabric's specification.

WOOD

Wood is a living material whose grain from the very beginning has a natural variation in pattern, color tone and luster. The wood is affected by, among other things, the season, heat and humidity. That wood is a living material means:

- Screws need to be re-tightened regularly, at least once a year.
- Solid table tops can naturally warp by up to 0.5%.
- Light from the sun and lighting can cause permanent color and light differences in the surface, so allow the entire wooden surface to be exposed to the same amount of light.

Out of concern for the environment, we paint a large part of our range with water-based surface treatments. This means:

- Spills of coffee and other liquids need to be wiped up immediately.
- For cleaning, hand washing detergent or pH-neutral detergents and lukewarm water are recommended. Wipe off with clean water and wipe dry. Do not use cleaning agents that are alkaline, aggressive, contain abrasives or solvents.
- For disinfection, non-alcohol-based agents are recommended, e.g. Virkon or DAX Alco Free. Alcohol-based agents must not be used.