



FUNCTIONAL ARMCHAIR

KARIN 215

Karin 215 is a functional armchair in birch wood, which is designed for, for example, nursing homes, care and care. It has removable upholstery that facilitates cleaning. The armchair can be adjusted on both sides, making it more accessible and user-friendly. Karin is tested for 160 kg user weight according to Möbelfakta's requirements.

Karin är ritad av Sylve Stenqvist.

DIMENSIONS

Height	112 cm
Width	72 cm
Seat height	46 cm
Seat depth	47 cm
Höjd armledare	60 cm



Any NCS-color available as an option on this product.

CERTIFICATIONS



VIEWS



ADDED VALUE

- Controls on both sides
- Removable upholstery
- Any color
- Tested for public use and meets the requirements for durability & safety, set forth in the following standard, EN 16139
- Tested for 160kg



ACCESSORIES

- Frame in birch
- Frame in any color
- Rubber fabric/hospital fabric
- Hemiplegia support with fixed upholstery
- Tray table

REUSE

- Solid wood
- Removable upholstery

NC Nordic Care AB

Box 30 573 35 Tranås Sweden

+46(0)140-38 40 60, info@ncnordiccare.se

ncnordiccare.se



METAL

- For regular cleaning, use a lightly moistened cloth with a mild detergent without solvents or abrasives.
- For heavily soiled surfaces, a cloth moistened with alcohol can be used.
- Disinfection can be done with alcohol if the surface is dried afterwards.

FABRIC

- Removable and washable fabrics are washed according to washing instructions. These are sewn with a shrink seam, wash before use for optimal fit.
- Vacuuming with a soft nozzle is often sufficient for cleaning.
- Stains should always be removed as quickly as possible. In most cases, wiping with a damp cloth is sufficient, for more difficult stains, a pH-neutral detergent or a foam detergent for professional use can be used.
- Always use white cloths and avoid wetting a woolen fabric to a greater extent, as this risks remaining stains.
- If necessary, a foam detergent can also be used for a more thorough cleaning if this is allowed in the fabric's specification.

WOOD

Wood is a living material whose grain from the very beginning has a natural variation in pattern, color tone and luster. The wood is affected by, among other things, the season, heat and humidity. That wood is a living material means:

- Screws need to be re-tightened regularly, at least once a year.
- Solid table tops can naturally warp by up to 0.5%.
- Light from the sun and lighting can cause permanent color and light differences in the surface, so allow the entire wooden surface to be exposed to the same amount of light.

Out of concern for the environment, we paint a large part of our range with water-based surface treatments. This means:

- Spills of coffee and other liquids need to be wiped up immediately.
- For cleaning, hand washing detergent or pH-neutral detergents and lukewarm water are recommended. Wipe off with clean water and wipe dry. Do not use cleaning agents that are alkaline, aggressive, contain abrasives or solvents.
- For disinfection, non-alcohol-based agents are recommended, e.g. Virkon or DAX Alco Free. Alcohol-based agents must not be used.