



FOOTSTOOL

KARIN 096

Karin 096 is a footstool in solid wood, with high function and quality. It is adjustable in two positions and fits the Karin 215 functional armchair. The footstool is covered with removable upholstery so it can easily be kept hygienic.

As an option, the footrest can be supplied with rubber fabric under the fabric of the cushion.

Karin är ritad av Sylve Stenqvist.

DIMENSIONS

Height	42 cm
Width	52 cm
Depth	40 cm



Any NCS-color available as an option on this product.

CERTIFICATIONS



The mark of responsible forestry

VIEWS



ADDED VALUE

- Adjustable in two positions
- Removable upholstery
- Any NCS color
- Tested for public use and meets the requirements for durability & safety, set forth in the following standard, EN 16139



ACCESSORIES

- Frame in birch or oak
- Frame in any NCS color
- Rubber fabric/hospital fabric

REUSE

- Solid wood
- Removable upholstery



FABRIC

- Removable and washable fabrics are washed according to washing instructions. These are sewn with a shrink seam, wash before use for optimal fit.
- Vacuuming with a soft nozzle is often sufficient for cleaning.
- Stains should always be removed as quickly as possible. In most cases, wiping with a damp cloth is sufficient, for more difficult stains, a pH-neutral detergent or a foam detergent for professional use can be used.
- Always use white cloths and avoid wetting a woolen fabric to a greater extent, as this risks remaining stains.
- If necessary, a foam detergent can also be used for a more thorough cleaning if this is allowed in the fabric's specification.

WOOD

Wood is a living material whose grain from the very beginning has a natural variation in pattern, color tone and luster. The wood is affected by, among other things, the season, heat and humidity. That wood is a living material means:

- Screws need to be re-tightened regularly, at least once a year.
- Solid table tops can naturally warp by up to 0.5%.
- Light from the sun and lighting can cause permanent color and light differences in the surface, so allow the entire wooden surface to be exposed to the same amount of light.

Out of concern for the environment, we paint a large part of our range with water-based surface treatments. This means:

- Spills of coffee and other liquids need to be wiped up immediately.
- For cleaning, hand washing detergent or pH-neutral detergents and lukewarm water are recommended. Wipe off with clean water and wipe dry. Do not use cleaning agents that are alkaline, aggressive, contain abrasives or solvents.
- For disinfection, non-alcohol-based agents are recommended, e.g. Virkon or DAX Alco Free. Alcohol-based agents must not be used.