



WIDE ARMCHAIR

JACKIE 1132 XL

Jackie is a versatile furniture family with armchairs, sofas and chairs with different functions and sizes with tactile materials that create a varied but harmonious and unified expression.

Jackie XL is created on the basis of all identified needs regarding a nursing chair. For example, it can be suspended, stackable and acoustically damped, which provides good cleaning routines, flexible furniture and a good sound environment when required.

It is available in different heights to suit different individuals, has a stable and tip-proof full-length arm with grip also in the back for support. Jackie XL is tested for 160 kg user weight according to Möbelfakta's requirements.

For best hygiene, Jackie has removable and washable upholstery and rubber fabric on the seat for best hygiene.

Möbelfamiljen är tillverkat i FSC-certifierat björk och är märkt med Möbelfakta. Jackie är ritad av Peter Andersson.

DIMENSIONS

Height	83 cm
Width	68 cm
Depth	58 cm
Seat height	46 cm
Seat depth	40 cm
Höjd armledare	66 cm



Any NCS-color available as an option on this product.

CERTIFICATIONS



VIEWS



ADDED VALUE

- Uniform expression with multifunctions
- Customizable according to individual and needs
- Offers many tactile materials
- Hangable
- Stackable (also with sliding wheels)
- Linkable
- Tip-proof full-length armrests
- Acoustic damped
- Removable upholstery
- Any NCS color
- Tested for public use and meets the requirements for durability & safety, set forth in the following standard, EN 16139
- Tested for 160kg





ACCESSORIES

- Frame in birch or oak
- Frame in any NCS color
- Upholstered seat
- Back cushion
- Back plate with horizontal ribs
- Sliding wheels
- Coupling fittings
- Acoustic board
- +5 cm seat height

REUSE

- Solid wood
- Removable upholstery
- Replaceable padding



LEATHER

If you take care of the leather in the right way, it will become more beautiful over the years.

- Leather is heat sensitive. Therefore, direct sunlight and close contact with heating elements should be avoided.
- Vacuum the furniture to remove loose dirt and dust.
- Wipe the leather with a slightly damp cloth and a mild soapy solution can be used for cleaning.
- Water-based leather care products extend the lifespan.

FABRIC

- Removable and washable fabrics are washed according to washing instructions. These are sewn with a shrink seam, wash before use for optimal fit.
- Vacuuming with a soft nozzle is often sufficient for cleaning.
- Stains should always be removed as quickly as possible. In most cases, wiping with a damp cloth is sufficient, for more difficult stains, a pH-neutral detergent or a foam detergent for professional use can be used.
- Always use white cloths and avoid wetting a woolen fabric to a greater extent, as this risks remaining stains.
- If necessary, a foam detergent can also be used for a more thorough cleaning if this is allowed in the fabric's specification.

WOOD

Wood is a living material whose grain from the very beginning has a natural variation in pattern, color tone and luster. The wood is affected by, among other things, the season, heat and humidity. That wood is a living material means:

- Screws need to be re-tightened regularly, at least once a year.
- Solid table tops can naturally warp by up to 0.5%.
- Light from the sun and lighting can cause permanent color and light differences in the surface, so allow the entire wooden surface to be exposed to the same amount of light.

Out of concern for the environment, we paint a large part of our range with water-based surface treatments. This means:

- Spills of coffee and other liquids need to be wiped up immediately.
- For cleaning, hand washing detergent or pH-neutral detergents and lukewarm water are recommended. Wipe off with clean water and wipe dry. Do not use cleaning agents that are alkaline, aggressive, contain abrasives or solvents.
- For disinfection, non-alcohol-based agents are recommended, e.g. Virkon or DAX Alco Free. Alcohol-based agents



must not be used.

NC Nordic Care AB

Box 30 573 35 Tranås Sweden

+46(0)140-38 40 60, info@ncnordiccare.se

ncnordiccare.se